

GLUE BRUSHES

Glue brushes are constructed with a plastic trim, rather than metal, to avoid any interaction or contamination of the adhesive. Available in three sizes (n.06, n.08 and n.10) and bags of 12.



PUT YOUR FEET IN OUR HANDS



mason grogan
MEDICAL

MATERIALS • KNOWLEDGE • PERFORMANCE

GLUE CONTAINERS



mason grogan
MEDICAL

MATERIALS • KNOWLEDGE • PERFORMANCE



1300 859 960



salesmg@grogangroup.com

108 - 110 Carnarvon Street
Silverwater NSW 2128 Australia

www.grogangroup.com

www.grogangroup.com

GLUE CONTAINERS

For a safer, healthier workplace and less wastage

- Less fumes due to small opening
- Less evaporation of solvents for longer glue life
- Automatic dosage apparatus
- Cap increases brush life
- Available in four sizes: 0.4L, 0.9L, 1.5L and 3.0L
- Ultrasonically sealed to ensure durability. Sealing guaranteed for 5 years



HOW TO USE

FILL THE CONTAINER



STEP 1

Tilt the container on its side as shown. Pour the adhesive into the hole.

USE THE BRUSH STAND



STEP 2

Convenient stand for brush while working with materials. This allows the brush to remain submerged in glue to prevent drying out.

QUICK & SIMPLE

LEAVE THE CAP ON



STEP 3

When not in use the container should be left with its special cap on, leaving the brush inside.

CHECK GLUE THICKNESS



STEP 4

If the glue becomes thick because the container has been open for a long time, replace the cap and tilt it to the filling position. It is recommended to keep it in the filling position over night.

NOTE: As for all flammable and evaporative products, it is recommended to keep the container away from fire, light and sun. When the container is not being used, it is recommended to keep it hermetically closed with blue cap.